


# LSM6DSV320X


For all is on you and  
around you

# Continue to unleash the potential of our cutting-edge MEMS sensors



# What's the LSM6DSV320X?

New sensor technology for accurate and efficient measurement of both high and low acceleration levels



Accurate and valuable insights for motion and intense impact tracking

Edge AI and self-configuration:  
FSM\*, MLC\*, ASC\* and SFLP\* embedded resources




\*FSM = finite state machine  
\*MLC = machine learning core  
\*ASC = adaptive self-configuration  
\*SFLP = sensor fusion low power

# Which attributes for LSM6DSV320X?



## High impact tracking

An innovative new mechanical structure for high and low accelerations



## Context identification

Edge AI computing and sensor fusion inside the sensor for spatial orientation



## Efficiency


Compact package with three fully synchronized sensors and adaptive sensor configuration (ASC)




# LSM6DSV320X

## Differentiating features for new applications

Industry-first high performance 6-axis IMU with a **dedicated high-g accelerometer** for intensity impact and shock detection




Top view of MEMS unit of LSM6DSV320X




# LSM6DSV320X

## Differentiating features for new applications




Enhanced **contextual awareness** with an IMU embedding AI and advanced processing features

MLC



FSM



ASC



SFLP



Emergency calls

Fall/drop reconstruction

Intense movements tracking

Concussion monitoring

# You and all around you Applications with LSM6DSV320X

## Smartphone & foldable



Emergency call

Human activity  
recognition

Lid angle detection

Camera: image  
stabilization

## Wearable



Emergency call  
Intense sports tracking

Human activity  
recognition

Context awareness

## Smart tags & IoT



Shock and drops  
impact tracking

Motion tracking

Context awareness

## PC, laptop, and tablet



High impact recording

Lid angle detection

Context awareness

## Gaming



Intense gestures

High impact recording

# Now, you can capture all events around you by yourself

## A comprehensive ecosystem for developers

### Software libraries



#### Motion XLF

Accuracy data (fusion of high-g and low-g)



#### Sensor fusion


Heterogenous data (different sensors' fusion)



#### Context awareness (MLC)

Human activity recognition, gesture from wrist

### Software tool



#### MEMS Studio

### Development kits

Professional MEMS tool  
(STEVAL-MKI109D)



[STEVAL-MKI251A](#)



SensorTile.Box PRO



Evaluate and program the LSM6DSV320X – Develop embedded AI features, design no-code algorithms



# LSM6DSV320X

## IMU for you and all around you

Innovative structure for optimized low-g and high-g sensing



### Flexible

Dual accelerometer with dedicated channels and self test

- Low-g accelerometer: up to  $\pm 16$  g
- High-g accelerometer: **up to  $\pm 320$  g.**
- Gyroscope: up to  $\pm 4000$  dps

### No overhead in the package size


- Compact IMU footprint: 2.5 x 3.0 x 0.83 mm

### At-the-edge processing

- Adaptive self-configuration (ASC)
- MLC<sup>(1)</sup> (1 kHz, 256 nodes), FSM<sup>(2)</sup>, SFLP<sup>(3)</sup>
- 1.5 KB FIFO (up to 4.5 KB with compression)
- OIS with Aux I<sup>3</sup>C interface (v1.1)
- And more...



### Automatic switch with FSM



(1) MLC: Machine learning core

(2) FSM: Finite state machine

(3) SFLP: Sensor fusion low power

# Why use LSM6DSV320X?

A photograph of a man in a red jacket and helmet riding a bicycle down a set of stone steps. He is smiling and looking towards the camera. The background shows a modern building with large windows. A yellow callout box is positioned over the upper right portion of the image, containing text about the LSM6DSV320X sensor.

**LSM6DSV320X enables solutions unlocking creativity and transforming applications**

- High-g sensing removing false positive detection
- High-fidelity dynamic signal tracking
- Always-on sensing in the best efficient way
- System level complexity reduction and efficiency



# LSM6DSV320X: comparison vs competitors

Features	LSM6DSV320X	Competitor IMUs
<b>Mechanical structure</b>	Three sensing elements in a single package <ul style="list-style-type: none"><li>• Gyroscope</li><li>• Low-g accelerometer (<math>\pm 16</math> g)</li><li>• High-g accelerometer (<math>\pm 320</math> g)</li></ul>	Two sensing elements in a single package <ul style="list-style-type: none"><li>• Gyroscope</li><li>• Low-g accelerometer (<math>\pm 32</math> g)</li></ul>
<b>Signal dynamics reconstruction</b>	Capable of high-fidelity motion tracking and reconstruction	Limited reconstruction of dynamics
<b>False-positive robustness</b>	High robustness with advanced filtering and signal processing	Basic filtering capabilities
<b>Edge AI</b>	Machine learning core and adaptive self-configuration	--
<b>Software libraries</b>	Motion XLF, sensor fusion, context awareness, basic libraries	Basic libraries for standard operations
<b>Target applications</b>	Superior functionality in mobile, IoT, and asset tracking devices	Limited functionality in standard wearable applications



# The perfect product for you and all around you

## LSM6DSV320X



**Industry-first IMU with dual MEMS accelerometer**  
Measures accurately up to 320 g full-scale range

**New frontiers for personal electronics and IoT**  
Emergency call, drops and falls tracking, concussion, etc

**Miniaturized AI-enabled sensor with context-awareness**  
for system level complexity reduction and efficiency

# Our technology starts with You



Find out more at [st.com/LSM6DSV320X](http://st.com/LSM6DSV320X)

© STMicroelectronics - All rights reserved.

ST logo is a trademark or a registered trademark of STMicroelectronics International NV or its affiliates in the EU and/or other countries.

For additional information about ST trademarks, please refer to [www.st.com/trademarks](http://www.st.com/trademarks).

All other product or service names are the property of their respective owners.

